


BACKPLATES


For OCTAGONAL BOX

- **Round backplate (AR50)**
4-1/2" Dia, 3/16" thick
- **Round backplate (AR51)**
5-1/2" Dia, 5/16" thick
- **Round backplate (AR52)**
5-1/2" Dia, 1/16" thick
- **Square backplate (AR70)**
4-1/2" x 4-1/2", 5/16" thick




For HANDY BOX

- **Rectangular backplate (AR60)**
2-7/8" x 4-1/2", 5/16" thick
- **Rectangular backplate (AR61)**
2-7/8" x 4-1/2", 1/16" thick



For SWITCH BOX

- **Rectangular backplate (AR65)**
1-1/2" x 4-1/4", 1/16" thick



For OTHER BOXES

- **Round backplate (AR53)**
6-1/2" Dia, 1/16" thick